


Blanchard River Highway Maintenance Section: Sheet 5 (km 101 to 111)



Highway Feature	Engineering Component	Environmental Component	Maintenance Advisory System	Section Specific Features	Notes:
AC = Access Points BP = Borrow Pits DNG = Drainage (Roadside Ditch, Run-off Control Structures, etc.) Q = Quarries RA = Rest Area RC = Rock Cuts/ Slide Areas PO = Pull Out CV = Culvert MP = Multiplate BR = Bridge UC = Utility encroachment /Crossing IS = Insulated Structure RS = Road Surface GS = Granular Source / Stockpile WX = Wildlife Crossing	US = User Safety (eg. Avalanche / Wildlife Area) IC = Icing Control RV = Revegetation (Existing Material, Revegetating & Reclaimed Areas) SF = Snow Fence (drifting control structure) SR = Snow Removal EC = Erosion Control ECP = Erosion Control Protected by Geotextile WM = Waste Management OH = Outhouse GT = Geotextile / Granular Filters	CU = Cultural Use HTG = Heritage BL = Boat Launch FH = Fish and/or Fish Habitat RCP = Residential / Commercial Property WQ = Water Quality REC = Recreation WH = Wildlife and/or Wildlife Habitat SV = Scenic Viewing	Notification Caution * Alert * Soil Remediation Advisory Revegetation Advisory Road Surface Advisory Caution Bar <small>* Confirm if special maintenance required (Vol. 2., Sec. 1.)</small>	Snow Poles * Champagne and Aishihik FN Settlement Lands 	BR038: Plow at Easter. BR039: Instream construction between 08/15 & 09/30. BR040: Instream construction between 06/01 & 09/01. BR041: Instream construction between 06/01 & 09/01. BR046: Wildlife crossing hazard between Nadahini Creek and Mule Creek airstrip.